

Wireless Range Extender V2.2

Mobile phone setup

1 Plug in your wifi extender and wait for 30s

***Normal:**
Plug in the power, wait 1 minute, the "WIFI" light turns green and go to the next step

Abnormal:
Press "reset" hole on the bottom of the product for 5s with paperclip or contact seller

2 Connect your extender SSID

Please connect to the SSID of "wifi-XXXX".

***NOTE:**
You can not surf the Internet until you finish all the setting steps, pls continue

"XXXX" is the last 4 digits letters of MAC Address which appears at the back of each product.



3 Open your browser webpage (Google/Firefox Browser Recommended)

***NOTE:**
Pls make sure that you have connected the SSID(wifi-XXXX) of the wifi extender successfully, most of the PC/Internet will recognize and sign in to the management page automatically.
If not, pls enter 192.168.188.1 on the new browser.



4 Enter the default password: admin




5 Scan and select your host router SSID




6 Enter the password of your host router

***NOTE:**
Pls make sure of the right password/special characters not allowed like "%".



7 Set your Extender SSID and password



8 Check again and confirm the wireless info

***NOTE:**
After check, click "Start Connect" and wait 30-60s



9 Wait for the repeater to connect to the router successfully.

After the setting is completed, please observe the signal indicator. If it lights up, it means that the setup is successful. Please connect to 'wifi-XXXX-pro' in the Internet after a few moments.

Please wait 47 seconds

10 The led light "Extender" will light up, that means it Extender Mode successfully.



11 Reselect and reconnect to your extender wifi




Reconnect the extender SSID, then get access to Internet

AP mode

If you need AP mode, please do RESET then follow STEP 1 to STEP 4

Click [AP Settings]



Set Wireless Password

Click [Auth Mode] — select the encryption method, generally select [WPA2PSK/WPA2PSK/AES] to finish wireless password setting. Click [Apply]



Plug the Ethernet cable to the LAN port directly then you can access the Internet.



Wireless Range Extender V2.2

PC setup step

1 Plug in your wifi extender and wait for 30s

***Normal:**
Plug in the power, wait 1 minute, the "WiFi" light turns green and go to the next step

Abnormal:
Press "reset" hole on the bottom of the product for 8s with paperclip or contact seller

2 Connect your extender SSID

Please connect to the SSID of "wifi-XXXX".

***NOTE:**
You can not surf the Internet until you finish all the setting steps, pls continue

"XXXX" is the last 4 digits letters of MAC Address which appears at the back of each product.

3 Open your browser webpage (Google&Firefox Browser Recommended)

***NOTE:**
Pls make sure that you have connected the SSID(wifi-XXXX) of the wifi extender successfully, most of the PC/mart will recognize and Sign in to this management page automatically. If not, pls enter 192.168.188.1 on the new browser.

4 Enter the default password: admin

Login

User Name: admin
Password: admin

Login

5 Scan and select your host router SSID

Different Channels working together would interfere signal, and the network speed will get slow. Please change the main router channel in time.

6 Enter the password of your host router

***NOTE:**
Pls make sure of the right password(special characters not allowed, like "%")

7 Set your Extender SSID and password

Pls make sure you have selected the right channel and password for your host router.

Pls make sure you have selected the right channel and password for your extender.

8 Check again and confirm the wireless Info

***NOTE:**
After check, click "Start Connect" and wait 30-60s

9 Wait for the repeater to connect to the router successfully.

After the setting is completed, please check the signal indicator. If it lights up, it means that the setup is successful. Please wait 47 seconds.

10 The led light "Extender" will light up, that means it Extender Mode successfully.

***NOTE:**

or Extender

11 Reselect and reconnect to your extender wifi

Before After

Reconnect the extender SSID, then get access to Internet

AP mode

If you need AP mode, please do RESET then follow STEP 1 to STEP 4. Click [AP Settings]

Set Wireless Password

Click [Auth Mode] ---- select the encryption method, generally select [WPA2PSK/WPA2PSK/AES] to finish wireless password setting. Click [Apply]

AP Settings

Wireless Name: wifi-XXXX
Channel: Auto
Auth Mode: WPA2PSK/WPA2PSK/AES

Plug the Ethernet cable to the LAN port directly then you can access the internet.

LAN Port